



1. PARTS IDENTIFICATION

HOSE END TIMER

1. Female swivel hose thread faucet/tap adapter
2. Interior filter
3. Top cover
4. Controller display
5. Programming and operation buttons
6. Male hose thread connection
7. Battery compartment



1



2. BATTERY INSTALLATION

- Hold the controller with the battery compartment facing you
- Remove the battery compartment cover
- Connect 9V battery to the battery connector
- Insert battery and press on battery cover
- Pay attention: when changing the battery, make sure the battery compartment stays dry.

Use Alkaline batteries only.



2

If no changes are implemented, the controller display will always revert to the main screen (clock). Display digits will stop blinking after 40 seconds. If the last parameter stops blinking before you have completed your programming, press to continue the process.

Emergency Irrigation: After inserting batteries if no buttons are pressed, the clock will blink continuously. After 10 minutes, the controller will implement 5-minute irrigation on a 24-hour cycle.

SETTING CURRENT TIME & DAY OF THE WEEK


Setting The Clock

To enable the irrigation controller to operate the irrigation system at the required times, the current time and day of the week must be set as shown below:

5


3. CONTROLLER/TIMER INSTALLATION

Make sure the filter (washer) is in place, then screw the controller to the faucet/tap by attaching the side with the female swivel hose thread connector to the faucet or hose end, then turn it clockwise (hand tighten only). Connect the controller hose male thread side to your system.



3

1. Press several times until appears.
2. Press . The hour digits blink. Set the current hour with the aid of or .



3. Press . The minute digits blink. Set the current minute with the aid of or .

6

4. IRRIGATION PROGRAMMING

This section contains an example of weekly irrigation program. Simply alter data in the example to adapt the program to meet your irrigation requirements. The digital controller is programmed with the aid of 4 buttons.

- Programming step – used to select the appropriate programming mode (e.g. clock setting mode).
- Parameter selection – used to select the parameter to be changed (e.g. hour, minute, etc.) To implement the change, the selected parameter must be blinking.
- Data increment (increase) – raises the value of the selected parameter (e.g. adds an hour)
- Data decrement (decrease) – lowers the value of the selected parameter (e.g. deducts an hour).

4

For a 24 hour clock display, press concurrently on and once the hour digits stop blinking.

Pressing these buttons again will revert the display back to AM/PM hour display.

Setting The Day Of The Week

1. Press until a blinking drop appears at the top of the display.
2. Set the drop on the current day of the week by pressing on or .

7

Hose Thread Watering Timer
Model 9001D and 9001DB

OPERATION MANUAL
INSTALLATION AND



PROGRAMMING A WEEKLY IRRIGATION SCHEDULE (SET DAYS OF THE WEEK)

Let's assume that we want to program the irrigation controller to water three times a day, at 8:00 a.m., 1:00 p.m. and 7:00 p.m., for 10 minutes each time, on Tuesday and Friday.

PROGRAMMING DURATION OF IRRIGATION


1. Press **⏸** until **⏸** appears opposite "Duration". The hour digits blink (0).
2. Press on **+** or **-** to change the watering duration in the example.
3. Press **⏸**. The minute digits will blink. Press on **+** or **-** until the minute digits reach 10.



8

PROGRAMMING IRRIGATION DAYS


1. Press **☀**. **☀** will appear opposite the word 'Days'. If you are programming the controller for the first time, the word OFF will blink on the display.
2. Press **☀**. A blinking **☀** will appear under Monday in the upper section of the display. Using **☀**, position the blinking marker under Tuesday, and press **+**. The marker under Tuesday will stop blinking and another marker will start blinking under Wednesday. Press **☀** twice more until the blinking marker reaches Friday. Press **+** again.



9

SETTING IRRIGATION START TIME/DATE

1. Press **⏸**. START I will appear on the display. Press **⏸**. The hour display will start blinking.
2. Using **+** or **-** set the start time at 08:00 AM (note the AM/PM indicators). Repeat this operation for the second irrigation period (START II) at 13:00, and for the third irrigation period (START III) at 19:00.
3. Press **⏸**. START IV will appear on the display. Press **⏸**. The hour digits will blink.
4. Press **+** or **-** until the word OFF appears on the display. The fourth irrigation start is canceled.




10

COMPUTERIZED MANUAL OPERATION

This option operates the valve for the defined irrigation period. The valve will close automatically at the end of the irrigation period. Note that the originally programmed irrigation schedule will continue to function at the set times. This setting cannot be implemented when the display is blinking.

Operation: Press **☀**. **☀** will appear next to the word 'Manual', and **☀** will appear underneath it.




11

IRRIGATION CONTROLLER SUSPENSION

This option is used to temporarily suspend irrigation controller operation, for example, while it is raining. The irrigation operation schedule remains in the controller memory but is not implemented until the suspension is canceled.

Suspension: Press **☀** for 3 consecutive seconds until the symbol **☀** appears.

Cancel Suspension: Press **☀** for 3 consecutive seconds to return irrigation system control to the irrigation controller. The **☀** symbol will disappear. During suspension, the "Manual" **☀** button will not function.



12

BLINKING LOW BATTERY WARNING

A blinking battery icon (**☀**) appears on the display when the batteries are low. At this point, the battery still contains a limited amount of energy for valve operation. The battery should be replaced promptly.

If the battery is not replaced, the irrigation controller will continue to open the valve 8 times according to the program. It will then suspend the program and OFF will appear on the screen. Program data will be retained for 30 seconds while changing battery.

13

MISSING DEFINITION IN IRRIGATION PROGRAM

noPr will appear when programming irrigation days (see Programming a Weekly Irrigation Schedule), if no irrigation days have been specified. In this case, the valve cannot be opened during the computerized manual operation (see Computerized Manual Operation).

5 Maintenance

Remove batteries if the irrigation controller will not be used for a prolonged period. The controller contains an internal filter, which has to be removed and cleaned every few months. If the filter is not cleaned on a regular basis - it could create problems. The life span of the battery is at least one year.



14

DIG CORPORATION 3 YEAR WARRANTY

DIG CORPORATION warrants these products to be free from defects in material and workmanship for a period of three years from date of purchase. This warranty does not cover damage resulting from accident, misuse, neglect, modification, improper installation or subjecting to line pressure in excess of 120 lbs. per square inch. This warranty shall extend only to the original purchaser of the product for use by the purchaser. This warranty shall not cover batteries or any malfunction of the product due to battery failure. The obligation of DIG CORPORATION under this warranty is limited to repairing or replacing at its factory this product which shall be returned to the factory within one year after the original purchase and which on examination is found to contain defects in material or workmanship. DIG CORPORATION SHALL IN NO EVENT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY KIND; THE SOLE OBLIGATION OF DIG BEING LIMITED TO REPAIR OR REPLACEMENT OF DEFECTIVE PRODUCTS. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU. Unattended use for prolonged periods without inspection to verify proper operation is beyond the intended use of this product, and any damage resulting from such use shall not be the responsibility of DIG CORPORATION. There are no warranties which extend beyond the description on the face hereof. In the case of purchase of the product for use other than for irrigation purposes, DIG CORPORATION hereby disclaims any implied warranties including any warranties of merchantability and fitness for a particular purpose. In the case of the purchase of the product for personal, family or household purposes, DIG CORPORATION disclaims any such warranties to the extent permitted by law. To the extent that any such disclaimer or implied warranties shall be ineffective, then any implied warranties shall be limited in duration to a period of one year from the date of the original purchase for use by the purchaser. Some states do not allow limitation on how long an implied warranty lasts, so the above limitation may not apply to you. In order to obtain performance under this warranty the unit must be returned to the factory along with proof of purchase indicating original date of purchase, shipping prepaid, addressed as follows: DIG CORPORATION, 1210 Activity Dr., Vista, CA 92083. Repaired or replaced units will be shipped prepaid to the name and address supplied with the unit returned under warranty. Allow four weeks for repairs and shipping time. Repair of damaged units not otherwise within warranty may be refused or done at a reasonable cost or charge at the option of DIG CORPORATION. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

© 2002 DIG Corp. Form 09-00

DIG
IRRIGATION PRODUCTS

1210 Activity Drive
Vista, CA 92083
800-322-9146
www.digcorp.com